

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Canon	VB-H47	1.0.0	Yes with restriction	Preset function is not available. The RTP over RTSP operation is not available. Camera function settings on the GUI of our products are not supported.
Canon	VB-M46	—	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S32D	—	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S32VE	1.0.0	Yes with restriction	Preset function is not available. The RTP over RTSP operation is not available. Camera function settings on the GUI of our products are not supported.
Canon	VB-S820D	—	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S920F	1.0.1	Yes with restriction	PTZ function is not available. The RTP over RTSP operation is not available. Camera function settings on the GUI of our products are not supported.
JVC	VN-H158WPR	—	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. H.264 is not available.
JVC	VN-H168WPR	—	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-H258R	—	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. H.264 is not available.
JVC	VN-H258VPR	—	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. H.264 is not available.
JVC	VN-H268R	—	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-H268VPR	—	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-H58	—	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. H.264 is not available.
JVC	VN-H658	1.00.079	Yes with restriction	The "EIZO Profile" is not available. Https is not available. PTZ operation is not available. Brightness operation is not available. Manual focus operation is not available. Auto focus operation is not available. Multicast stream is not available. H.264 is not available.
JVC	VN-H658WP	—	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. H.264 is not available.
JVC	VN-H678WPR	—	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-H68	—	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-U178WPR	—	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-U78	—	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
MITSUBISHI	NC-9000	0109t	Yes with restriction	The camera cannot be automatically detected. Register the camera manually. Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.
MITSUBISHI	NC-9020	0109t	Yes with restriction	The camera cannot be automatically detected. Register the camera manually. Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.
MITSUBISHI	NC-9600	0109t	Yes with restriction	Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.
MITSUBISHI	NC-9620	0109t	Yes with restriction	Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
MITSUBISHI	NC-9820	0109t	Yes with restriction	The camera cannot be automatically detected. Register the camera manually. Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.